


EVOLUTION



SMART PORTABLE ENAIL E-RIG

ENJOY ANYTIME ANYWHERE

PARTS BREAKDOWN



- A. LOADING TOOL
B. COTTON SWABS
C. USB - C CABLE
D. AC ADAPTER
E. WATER BUBBLER
F. CARB CAP
G. ATOMIZER COVER
H. QUARTZ DISH (2)
I. ATOMIZER
J. CHARGING PORT

2

QUICK START



FULLY CHARGE DEVICE BEFORE FIRST USE. WHILE CHARGING, LED POWER INDICATOR ABOVE POWER BUTTON PULSATES RED AND TURNS GREEN WHEN FULLY CHARGED.



FILL GLASS WITH WATER JUST ABOVE THE AIR HOLES LOCATED INSIDE INNER GLASS. DO NOT ALLOW WATER IN BASE CONNECTION OF GLASS THAT CONNECTS TO THE MAIN BASE

3



ALIGN AIR HOLE INLET ON THE BASE OF THE GLASS WITH THE HOLE INLET ON THE ATOMIZER BASE. CAREFULLY PUSH THE GLASS INTO THE BASE WHILE TWISTING INTO PLACE.



CLICK 2X DURING HEATING CYCLE TO SHUT OFF HEATING (CYCLE). CLICK THE POWER BUTTON 5 TIMES TO POWER ON / OFF THE DEVICE.

4

SETTING THE TEMPERATURE




CLICK 1X TO CHANGE THE TEMPERATURE
BLUE / 437°F (225°C)
GREEN / 445°F (235°C)
RED / 473°F (245°C)
WHITE / 509°F (265°C)



CLICK 2X TO START HEATING CYCLE. THE DEVICE WILL VIBRATE AND THE LED LIGHTS WILL PULSATE DURING THE ENTIRE HEATING CYCLE. CLICK 2X MORE IF YOU WANT TO STOP HEATING CYCLE EARLY

5




THE UNIT WILL VIBRATE WHEN IT REACHES ITS TARGET TEMPERATURE. AFTER THE 15 SECOND PREHEATING CYCLE, IT WILL MAINTAIN CONSTANT TEMPERATURES FOR ANOTHER 35 SECONDS.



USE THE LOADING TOOL TO PLACE CONCENTRATE ON THE BOTTOM SURFACE OF THE BOWL.

6



PLACE THE CARB CAP ON TOP OF THE ATOMIZER AND INHALE.



USE COTTON SWABS TO CLEAN QUARTZ CHAMBER AFTER EACH USE.

7


TEMPERATURE SETTINGS



CLICK 1X TO CHANGE THE TEMPERATURE. THE LED WILL CHANGE ACCORDING TO TEMPERATURE

BLUE / 437°F (225°C)
GREEN / 445°F (235°C)
RED / 473°F (245°C)
WHITE / 509°F (265°C)

BATTERY LEVEL



THE BATTERY INDICATOR ABOVE THE POWER BUTTON IS ON DURING OPERATION. THE COLOR OF THE LED WILL INDICATE THE BATTERY LIFE REMAINING

8

CLEANING & MAINTENANCE



1. MAKE SURE THE DEVICE IS COOL ENOUGH TO TOUCH. REMOVE GLASS WATER BUBBLER, CARP CAP, ATOMIZER
2. EMPTY FROM THE GLASS WATER BUBBLER. RUN HOT WATER THROUGH GLASS UNTIL RESIDUE HAS MOSTLY REMOVED. THEN SOAK THE GLASS IN 99% ISOPROPYL ALCOHOL. NOTHING LESS <99%.
3. DISASSEMBLE ATOMIZER WHILE SLIGHTLY WARM. NEVER DISASSEMBLE HOT. AVOID BURNS. NEVER DISASSEMBLE COLD TO AVOID QUARTZ BUCKET FROM DAMAGING HEATING ELEMENT DUE TO THE GLUE NATURE OF COLD CONCENTRATES. SOAK QUARTZ DISH OR TORCH IT TO CLEAN IT. (QUICK CLEAN) SOAK ATOMIZER IN ONLY 99% ISOPROPYL OR (SAFE SLOWER CLEAN) TURN IT UPSIDE DOWN FOR 24 HOURS. ALL THE RECLAIM COMES OUT THIS WAY.
4. MAKE SURE ALL PIECES ARE COMPLETELY DRY BEFORE ASSEMBLING WATER BUBBLER OR ATOMIZER BACK TO THE DEVICE
5. USE COTTON SWABS TO CLEAN THE INSIDE OF THE QUARTZ DISH OF THE ATOMIZER CHAMBER AFTER EACH USE.

9

CHARGING

CONNECT THE USB-C CABLE INTO THE CHARGING PORT TO START THE CHARGING CYCLE. DO NOT USE OTHER ADAPTORS. THEY ARE NOT COMPATIBLE AND MAY DAMAGE THE UNIT. ANY USB CABLE IS ACCEPTABLE.

THE LED LIGHT WILL PULSATE RED WHILE CHARGING. THE LED LIGHT WILL TURN TO GREEN WHEN FULLY CHARGED.

DO NOT USE DEVICE WHILE CHARGING

IN CASE OF IMPROPERLY INSTALLED BATTERY THE UNIT COMES WITH REVERSE CONNECTION PROTECTION

DURING STORAGE AND SHIPPING WE USUALLY PACK THE BATTERIES REVERSED TO MAKE SURE THERE IS NO AUTOMATIC OPERATION DURING TRANSIT.

PCB PROTECTION

5 RED FLASHES AND VIBRATION = LOW VOLTAGE
3 RED FLASHES AND VIBRATION = INDICATES SHORT CIRCUIT, ATOMIZER IS DAMAGED, OR NO ATOMIZER

LEGAL WARNING

- THIS PRODUCT IS NOT FOR PEOPLE UNDER THE AGE OF 21 OR LEGAL AGE IN YOUR COUNTRY. STRICTLY USE AS INTENDED. THIS SHOULD BE USED ONLY BY PERSONS OF LEGAL AGE IN ACCORDANCE WITH LOCAL, STATE AND FEDERAL LAWS.
- USE THIS DEVICE RESPONSIBLY.

10

WARNING

- ALWAYS ALLOW THE UNIT TO COMPLETELY COOL BEFORE TOUCHING OR CLEANING. DO NOT TOUCH THE METAL COMPONENTS OR CHAMBER AFTER USE, UNTIL THE UNIT HAS COOLED.
- NEVER USE WHILE CHARGING.
- KEEP THE MAIN DEVICE DRY AND NEVER EXPOSE IT TO WATER, MOISTURE, LIQUIDS OR HIGH HUMIDITY.
- STORE IT IN A COOL DARK PLACE WHEN NOT IN USE.
- DO NOT STORE THE DEVICE IN THE CARRYING BASE WITH WATER INSIDE THE GLASS BUBBLER.
- DO NOT EXPOSE DEVICE TO EXTREME OR DIRECT SUNLIGHT.
- DO NOT DROP THE UNIT OR ACCESSORIES. DO NOT SUBMERGE IN ANY LIQUID.
- DO NOT MODIFY THE ELECTRONICS IN ANY WAY.
- ALLOW THE FULL COOL DOWN BETWEEN CYCLES OR CLEANING.
- DO NOT ALLOW WATER IN THE WATER BOTTOM CHAMBER OF THE ATOMIZER.
- DO NOT CHARGE OR OPERATE IT AT TEMPERATURE BELOW 32°F (0°C) OR ABOVE 100°F (37°C)
- THIS PRODUCT IS NOT A MEDICAL DEVICE AND IS NOT INTENDED TO DIAGNOSE, TREAT, CURE, OR PREVENT ANY AILMENT, DISEASE OR ANY OTHER MEDICAL CONDITION.
- DO NOT USE IF PREGNANT, BREASTFEEDING OR MAY BECOME PREGNANT.
- DO NOT SUBMERGE IN ANY LIQUID DURING CLEANING.


12

TAG US

#710LIFE
#EVOLUTION
#EVOLUTIONENAIL
#ENAIL

BE THE NEXT INFLUENCER
TO RECEIVE OUR FINEST

BE PART OF THE CULTURE





710 Life

FOR REPLACEMENT PARTS

VISIT: **420LIFE.COM**

LAUGH MORE, LOVE MORE, ENJOY MORE!

THANK YOU FOR CHOOSING 710 LIFE!
AMERICA'S MOST AWARDED ENAIL



420 LIFE® AND 710 LIFE® ARE REGISTERED TRADEMARKS
ALL RIGHTS RESERVED 420LIFE.COM
© COPYRIGHT 1992-2020